

Tent Rental Instructions





Requirements: You will require a standard hammer and 3-5 people.

Call Rachel with questions: 731-2424

Set up Directions:

- 1- Place **centre ring** down approximately in centre where tent will sit.
- 2- Insert skinny poles (1.5" diameter) into ring, like **spokes** on a wheel. (These will be the roof)
- 3- Attach corners "**chicken feet**" to ends of each skinny pole. Insert pins as you go.
- 4- Attach thicker 10' (2" diameter) poles into each corner. (These will be horizontal, making it look like a big wheel. We'll call these **wheel poles**.) Don't forget the pins.
- 5- Pull tent top over frame. Secure ALL straps to outer poles.
- 6- This is where you'll need help: 3-5 people. Lift the entire frame while 1 or 2 people insert the 8.5' (2" diameter) posts. (these will be vertical, like walls. Let's call these **wall posts**).
- 7- Under each **wall post**, place a piece of the provided plywood on the ground. Run a heavy spike down through the post into the plywood and ground.
- 8- Heavy car axels act as **tent pegs**. Use provided sledge hammer to drive axels into the ground slightly behind each wall post.
- 9- Secure **tent pegs** to corner "**chicken feet**" with provided ropes.
- 10- Attach any/all walls to **wheel poles** (same as the tent top). Secure all straps. Please store wooden crates in dry location – inside the tent even.



Tear Down Instructions: Follow **exact reverse** of set up directions.